



TM

- 1) If you have a combination lock, reset your combination before you start the installation.
- 2) Remove all your contents from the compartment, including the pad at the bottom.
- 3) Slip the vault down into the console, open the lid of the vault and notice three pre-drilled holes on each side of the vault. Mount the vault using the six self tapping screws that came with the kit.
- 4) Put the pad that came with the kit down in the bottom of the vault.