



- 1) Place the support arms in the bottom of the factory console; note the footprint for the front and rear, these parts will only fit in one position.



- 2) It is best to tape the lip assembly in place as shown below, this will allow you to place the support arms in position.



- 3) Remove the factory nuts in the bottom of the console and attach the support bracket, it is best to secure the front first and then the rear, do not tighten the nuts. There will be a final fitting.
- 4) Align the support bracket bolts to the holes in the lid assembly and finger tighten the nuts. When everything is loosely attached you may tighten all hardware.