

console vault

unique security solutions

Model# 1050

**2014-FWD 1500 Silverado / Sierra
2015-FWD 2500 Silverado / Sierra,
Tahoe, Suburban, Yukon
Installation Instructions**



Hardware Included:

Two M6-1.0 x 30mm Machine Screws

1) Remove all contents from your factory console. Remove the two “factory” mounting bolts in the bottom of the factory console and place aside. (see fig. 1)



Figure 1

2) Notice at the top edge of both the passenger side and driver side there are “file hangers”, these need to be removed. Looking at figure 2, gently pry-out on the center portion of the hanger while sliding the hanger towards the front of the vehicle, they should “pop” right out. Place them aside.



Figure 2

3) Next slip the vault down into the center console, open the lid and using the replacement screws that came with the vault mount the vault.

4) Take the two file hangers that were removed in step 2 and put them back into place. You will no longer have the use of the hangers but it will cover up the exposed holes.

5) Next put liner in the bottom of unit and installation is complete