



CONSOLE VAULT®
INNOVATIVE SECURITY SOLUTIONS

800-878-1369 www.consolevault.com

**2020-2021 Ford Escape
1101 Instruction Sheet**



- 1) Reset the combination lock before beginning the installation.
- 2) Remove all the contents from the center console, including pad at bottom.
- 3) Slip In-Vehicle Safe down into the center console.
- 4) Open lid of the safe and notice four threaded fittings, two on the driver's side and two on the passenger side.
- 5) Next take the four self-drilling screws from the hardware kit and finger them into each fitting.
- 6) Tighten each of the self-drilling screws using a socket wrench, **DO NOT OVER TIGHTEN**, these screws are designed to cut their own hole while turning. Once the screw is fully seated, STOP. Over tightening will damage the fitting.
- 7) Place the pad in the bottom of the safe, installation is complete.