



CONSOLE VAULT®

INNOVATIVE SECURITY SOLUTIONS

800-878-1369 www.consolevault.com

Ford Edge 2020+ 1112 Instruction Sheet



- 1) Reset the combination lock before beginning the installation.
- 2) Remove all contents from the center console including the OEM console tray.
- 3) Slip In-Vehicle Safe down into the center console.
- 4) Open the door of the safe and notice four threaded fittings, two on the driver and passenger sides.
- 5) Hand thread the four self-drilling screws from the hardware kit into each fitting.
- 6) Tighten each of the self-drilling screws using a 7/16" or 11mm socket, crescent, or adjustable wrench, **DO NOT OVER TIGHTEN**, these screws are designed to cut into the center console while turning. Once the screw is fully seated, **STOP**. Over tightening will damage the fitting.
- 7) The installation is now complete!



Step 3)



Step 5)



Step 6) **DO NOT OVER TIGHTEN**